


How to Install Door Sensor

Proteus DX WiFi Door Sensor uses a magnetic reed switch to detect opening and closing of doors, windows and cabinets. After you have completed the Wi-Fi Setup process outlined in the Quick Start Guide, Position the door switch with the cable on the frame of the door. Place the magnetic (with no cables) on the door, adjacent to the switch such that in closed position, the magnet closes the reed switch due to its magnetic field.



Emails, Calls, Text Alerts

You can add your phone numbers, multiple emails to the notification list. No matter where you are, you can be in the know when water is detected.

Testing Your Sensor

After the installation is complete, try open the door to trigger the alarm. In few seconds, the base unit will start beeping with the amber light flashing. This indicates the alarms have been tripped and you should get notifications shortly.